A-dec 500 Cuspidor
Quick Start Guide

How to Operate the Cuspidor

The cuspidor comes factory preset with an automatic timed cup fill of five seconds and bowl rinse of 30 seconds. Both the cup fill and the bowl rinse functions can be reprogrammed.

Cup Fill Button

The cup fill function allows water to flow from the cuspidor cup fill spout into a cup. A quick press of the cup fill button activates a timed operation. A long press activates a manual operation.

Bowl Rinse Button

The bowl rinse function provides rinse water for the cuspidor bowl. A quick press of the bowl rinse button activates a timed operation. A long press activates the manual operation.

If the button is pressed twice in less than two seconds, the continuous operation will be activated. To stop the continuous bowl rinse operation, press the bowl rinse button once. There is no maximum time limit for this function.

Programming the Cuspidor

Cup fill and bowl rinse functions can be reprogrammed using a touchpad or the footswitch program button and the appropriate button on the cuspidor.

Step	Action
1	Press the **Program** button (one beep).
2	Press and hold **Cup Fill** or **Bowl Rinse** button for desired time.
3	Release button (three beeps).

Limit Switches

If activated, the limit switches will interrupt the base down motion and reverse the chair to prevent damage.

Copyright © 2004 A-dec Inc.
All Rights Reserved.

86.0604.00
2003-12 Rev. A (04123.13)

Gravity Drain Cleaning

At the end of each day, flush the drain to remove debris which can collect in the flexible drain tubing. If the drain is not flushed regularly, debris may build up and impair cuspidor draining. To flush the drain, raise the chair to its highest position and run the bowl rinse several times, long enough so that water flows down the drain for about 60 seconds.

CAUTION: Do not empty the solids collector or bowl screens into your cuspidor. Doing so could plug the cuspidor drain. After cleaning, always install the bowl screen in the cuspidor bowl drain to prevent debris from plugging the drain.

Cleaning the Cuspidor

The cuspidor is designed for quick and easy cleaning. The contoured spouts and the smooth cuspidor housing help facilitate more complete cleaning. When cleaning, do not remove spouts. This will help prevent cleaning solutions from causing potential equipment damage and contamination of the water flowing to the cup. Also, remember to empty and clean the bowl screen.

Copyright © 2004 A-dec Inc.
All Rights Reserved.

A-dec 500 Cuspidor

Maintenance Record

Date of Service	Model/Description of Service	Technician's Initials